





TOP HANDLE

LENS SUPPORT

ROD ADAPTER

1

将FP机身装入专用笼子




对应机身左侧壁安装孔
将螺丝拧紧

2

对应机身右侧壁
安装孔将螺丝拧紧

对应机身底部安装孔
将螺丝拧紧




3

15MM导轨适配孔位
可装载EVF支架并扩展
各类支撑附件

上手提插入1/4螺丝孔
后将手扭锁紧
(选配)


上手提前端冷靴槽
带保险限位设计

侧臂单孔导轨
适配器(选配)



4

硬盘支架
(选配)



取景器安装方式

木质手柄安装

5


底部单孔导轨
适配器(选配)

TYPE-C线卡
(选配)

HDMI线卡
(选配)


镜头转接环支撑
(选配)

扩展热靴组件安装方式
(选配)



6

将机身完全滑入底座
安全销弹起, 锁紧开关
(选配)




15mm单孔导轨适配器
可装载15mm导轨扩展
各类支撑附件


燕尾滑槽
可搭配通用燕尾滑板

7

侧手柄
(选配)




注: 更换手柄安装位置时
卡件及位置也需更换




1/4转接ARRI齿盘 (选配)

通用型转接齿盘, 可用于
ARRI接口手柄/齿盘接口手柄
实现左右通用



SIGMA FP




TOP HANDLE

LENS SUPPORT

ROD ADAPTER

1

Install FP camera into the cage




Fasten the left hand side screw

2

Fasten the right hand side screw

Fasten the bottom screw




3

15mm rod mounting hole for EVF holder or other supporting accessories.

Insert the top handle into the 1/4 screw hole then fasten. (Optional)


Cold shoe mount with stopper

Single rod side adaptor (Optional)



4

Hard drive holder (Optional)



Viewfinder mounting point


Wooden handle mounting point

5

Single rod base adaptor (Optional)

TYPE-C cable clip (Optional)

HDMI cable clip (Optional)




Hot shoe accessories mounting point (Optional)

6

Slide the camera onto the baseplate till the stopper is up right then fasten (Optional)

15mm single rod adaptor (for 15mm rod accessories)


Dovetail slot for dovetail plates



7

Side handle (Optional)

Note: mounting the adaptor on the correct side according to the position of the handle.



1/4 to Arri rosette converter (Optional)
compatible with Arri standard handle and rosette handle, can be installed on right or left side